



# ⚠️ **WARNING**

Read all the instructions in the **USER MANUAL** and follow the instructions!


The dryer is in a **TRANSPORT MODE** when you receive it. Remove the **ORANGE TRANSIT BAR** from underneath the dryer and keep the transit bar and bolts.



The drain hose is in the **TRANSPORT MODE**. Pull down the drain hose so that it slopes down along all its length. The **WHITE MARK** on the drain hose must always be visible underneath the product when the dryer is in **OPERATION**.





Install a **PROTECTIVE PLATE** underneath the dryer using the same bolts from removed transit bar. The protective plate must be always in **OPERATION MODE**.



# ⚠️ **WARNING**



The RCCB is in the TRANSPORT MODE, turn it ON by flipping the switch.



Keep all the PACKAGING including the CARDBOARD BOX, FOAM PROTECTIVE PADS and ORANGE TRANSIT BAR should you ever need repair of the dryer as this is the ONLY SAFE way to ship the product.



Place ONLY 1 PIECE of swimsuit inside the drum with strings facing down. The swimsuit must be entirely UNDER THE BRUSH SEAL otherwise, it could get damaged.



All extracted water must go through the drain hose. In case the water runs down the engine and drops from the bottom of the dryer, your waste hose is clogged. In that case, immediately clean the waste hose or install a new one.

